


## Problem:


My fluorescent light in the kitchen or laundry room is flickering or out.

## Solution:

- 1) Turn light off at the switch.
- 2) Grab a step ladder or other sturdy object to gain access to the light
- 3) Remove the plastic cover from the light fixture by gently pushing up and over.
- 4) Remove bad tube by twisting it 90 degrees and gently pull out.



- 5) Install new tube by lining up prongs and turning 90 degrees and gently pull out.



- 6) Test light with switch on wall. Once tested, turn light off again.
- 7) Replace fixture cover.
- 8) If a problem still exists, please contact management

Video Resource - <https://www.youtube.com/watch?v=zQHJRyIV5nY>