

Problem:

My smoke detector keeps beeping randomly.

Solution:

1) Find the smoke detector that is beeping.

2) Watch the smoke detector for a few minutes.
A green or red light will flash every 30 - 60 seconds indicating the status of the unit.



Red = Battery needs replaced

2) Grab one new 9v battery



3) Grab a step ladder or other sturdy object to gain access to the smoke detector.

4) Open battery access panel



or



5) Replace old battery with fresh battery and close access panel.
It will alarm briefly indicating normal function.

6) Test smoke detector by pressing the "Test" button.



7) Properly dispose of battery.

8) If the smoke detector continues to beep, contact management.

Video Resource : <https://www.youtube.com/watch?v=C9iKopZ2NeU>